




INSTALLATION INSTRUCTIONS

HONDA INSTALLATION INSTRUCTIONS	Accessory	Application	Publications No.
	TITANIUM SHIFT KNOB P/N 08U92-S2A-100	2000 S2000	All 20597 Issue Date AUG 1999

PARTS LIST

Shift knob




TOOLS REQUIRED


14 mm Combination wrench

INSTALLATION


1. Loosen the shift lever flange nut, then remove the knob by turning it counterclockwise.



2. By hand, thread the flange nut all the way down to the last thread. Do not allow the bottom of the flange nut to extend over the last thread of the shift lever.



3. By hand, thread the new shift knob onto the shift lever until it bottoms against the flange nut.



4. Adjust the shift knob in the correct direction, and tighten the flange nut securely.

