



# INSTALLATION INSTRUCTIONS

Accessory

**SHIFT KNOB (M/T)**  
P/N 08U92-SCV-100A

Application

**ELEMENT**

Publications No.

**All 33359**

Issue Date

**AUG 2006**


## PARTS LIST

Shift knob




## INSTALLATION

1. Remove the shift knob by pulling down on the trim ring, and rotating it counterclockwise.



2. Install the new shift knob by rotating it clockwise. Adjust the knob so that the shift pattern on the top is in the correct direction.



3. Engage the cutouts in the trim ring with the retaining tabs of the knob by pulling the boot upward.